

Pesaro

Maintenance advice

TYPE OF WOOD Old
ORIGIN Teak
COLOR (OPTIONS) Asia
OTHER MATERIALS Teak
FINISHING Steel

_

GENERAL TIPS AND ADVICE

Wood shrinks and expands due to external influences like humidity and temperature. A humidity of 55% to 65% and a constant room temperature of 20°C are the ideal conditions. Large differences in humidity and temperature can cause the wood to crack. If you have a room and/or rooms with varying levels of humidity, we advice to use a humidifier to help stablize the general level of humidity throughout the whole year. It is important not to place your furniture directly next to a heating source or airconditioning. In addition to this, avoid placing furniture in (direct) sunlight. Colors will fade sooner and lacquer and/or varnishes will wear off sooner which increases the likelihood of damages by normal daily use. Always use coasters and if you spill something, make sure to wipe this off as soon as possible. Also don't place any hot items on the furniture.

PERIODIC MAINTENANCE / CLEANING ADVICE

Daily maintenance: A damp cloth and mild dish soap are usually all you need to clean your furniture. After cleaning, rinse with a soap free and slightly damp cloth. Then dry the surface with a dry towel. Avoid aggressive and ammonia containing substances at all times when cleaning.

Periodic maintenance: Clean 2 or 3 times per year with Woodclean and treat it with Mat Polish for protection (both products are from Oranje B.V.).